



1

When the the Topeak APP is open on your device, click on the 3 circles on the bottom of the screen.




2

Then click on the "+" sign at the top. Spin the front fan while it searches for the Sensor. Once the Sensor is picked up by your APP, click on the Sensor to set the wheel size.



3

Click on wheel size to set. Once this screen appears below where "Custom" is selected click on "DONE" It will then take you back to the screen below.



4

Again click on "Wheel Size" The next screen below will appear & this is where you can set the wheel size to "0.265/0265" as shown below. Thereafter, click done.

